

GRAND RENTAL STATION  
POPCORN MACHINE INSTRUCTION  
(908)850-8515  
105 MAPLE AVE.  
HACKETTSTOWN, N.J.  
07840

#### CONTROLS AND THEIR FUNCTIONS

THERE ARE THREE SWITCHES ON THE POPPER.

##### LIGHT AND WARMER SWITCH

          TURNS ON THE HEAT TO THE BOTTOM CORN PAN AND HEAT LIGHT.

##### KETTLE MOTOR SWITCH

          TURNS ON THE MOTOR WHICH DRIVES KETTLE AGITATOR SHAFT.

##### KETTLE HEAT SWITCH

          TURNS ON THE HEAT ELEMENT.

#### POPPING INSTRUCTIONS

1. TURN KETTLE HEAT AND KETTLE MOTOR SWITCH ON.
2. MAKE TEST POP BY PUTTING 3 KERNELS OF CORN AND 1 OZ. OF OIL INTO THE KETTLE.
3. WHEN THE 3 KERNELS HAVE POPPED, LOAD KETTLE WITH CORN AND OIL CHARGE.
4. WHEN CORN HAS POPPED, DUMP KETTLE.
5. REPEAT CYCLE STARTING WITH ITEM #3: ALWAYS POP 3-5 BATCHES FOR BEST POPCORN.
6. AFTER POPCORN HAS POPPED, TURN OFF KETTLE TO AVOID BURNING OF LEFT OVER POPCORN.
7. KETTLE IS VERY HOT. AVOID TOUCHING.

NOTE: PLEASE CLEAN OUT ANY LOOSE POPCORN AND KERNELS.